10L-headstock-location-pins:

The pin that locates the headstock to the bed.

I measured the headstock alignment pin holes in the bed of my heavy 10 and the hole is \sim .312" while the headstock hole is .350"

Alec Ryals

The locating pin does not have to be a precision fit in the bed and the headstock. It's purpose is simply to keep the headstock in alignment with the gears on the banjo and the gearbox -- this saves you a few minutes of assembly time.

Alan Noah
